



**THANK YOU FOR PURCHASING YOUR 2 DOOR METAL CABINET RED.**

Please carefully read and follow these instructions to assemble your cabinet.






















**ENSURE PROTECTIVE EYEWEAR AND GLOVES ARE WORN WHEN ASSEMBLING THIS UNIT.**

**WARNING: SERIOUS INJURY CAN BE CAUSED BY TOPPLING FURNITURE.** To help prevent tip-over, we recommend you anchor this product to a wall or other suitable surface. Check anchors regularly.

## Pre-assembly Guidelines

1. Two people are required to finish the assembly.
2. Thoroughly read all instructions before starting assembly.
3. Read, understand and heed all warnings and safety instructions.
4. Plan to assemble the cabinet in the area where it will be used. Once fully assembled, the cabinet is difficult to move.
5. Wear proper eye protection and other applicable safety equipment while assembling.

## Components

	1 x Door Frame Arrow mark		1 x Left Side Panel Arrow mark
	1 x Right Side Panel Arrow mark		1 x Back Panel
	4 x Shelf		1 x Top Plate Screw holes on rims
	1 x Bottom Plate Front cutting edges		1 x Door With Lock
	1 x Door		2 x 500mm Side Baseboard
	1 x 910mm Front Baseboard		4 x Adjustable Legs
	4 x Fixed Legs		16 x Shelf Brackets
	16 x M5x12 Screws		4 x M5x6 Bolts
	6 x M5x12 Bolts		8 x M6x12 Bolts
	1 x Hex Key		4 x Pins
	4 x Plastic Washers		

**Step 1** Attach back panel and right panel using 5 x M5x12 screws.



**Step 2** Attach back panel and left panel using 5 x M5x12 screws.



**Step 3** Attach door frame with back and side panels from inside. Please make sure frame is tightly embedded in side panels' folded edges.



**Step 4** Assemble top plate from inside using 6 x M5x12 screws. The screw holes are on front and back rims.



**Step 5** Install fixed legs using M6x12 bolts and install adjustable legs later. If floor is uneven, please adjust adjustable legs by using hex key to desired height.



**Step 6** Cover bottom plate and fix side and front baseboards using M5x12 bolts.



**Step 7** Fix Door With Lock with pin and plastic washer using M5x6 bolts and assemble the other door in the same way.



**Step 8** Set shelf brackets and shelves to preferred positions.

